

OPTIONS

WIRELESS FOOT SWITCH



Wireless foot switch includes both variable speed and directional control with one foot. Variable speed is controlled with the main foot pedal, while a micro-switch on the side wall controls direction. Foot pedal has approximately a 60' range and up to 5 systems can work in the same work area without fear of interference. Battery life is estimated at 4,000 Hrs. Based on a 50% duty cycle.

**Wireless control for all Positioners,
Rolls and Turntables**



KOIKE ARONSON, INC. / RANSOME

P.O. Box 307, Arcade, New York 14009
Phone (585) 492-2400 Fax (585) 457-3517
www.koike.com

Features

- ◆ 2.4 GHz. frequency
- ◆ Variable speed control
- ◆ Fwd / Rev control



Selector switch provided to switch between foot switch control and hand pendant.



Wireless switch box on 20' cable. Can be located on machine or wall mounted for improved reception.